

**Woo Audio TUBE mini
Headphone Amplifier and DAC
with Mighty-Drive**



Have questions? call (917) 773-8645 or email us
at info@wooaudio.com



wooaudio.com
Where Better Sound Begins

**BEFORE YOU USE ME
please read the important
handling information.**

- TUBE mini utilizes traditional vacuum tubes; some care is necessary.
- Use the supplied USB-C adapter to connect your favorite Apple, Android, and Windows device.
- Best with hard-to-drive full-sized headphones.
- TUBE mini delivers FULL output when powered ON. Please follow the connection steps outlined here for the best results.
- Phone calls, SMS and other notifications may sound louder than the music. We recommend using a non-primary phone or tablet with "do not disturb" enabled for uninterrupted music listening.
- Cellular data signals (4G LTE and 5G) emit a high level of EMI and may interfere with the vacuum tubes resulting in audible noise. Download your music from streaming services for the best sound quality.
- Tapping on or handling the TUBE mini while in operation causes vibrations in the tubes (microphonics). A ringing sound may be audible.



**Connection for headphones with 4.4mm jack
[BALANCED]**

- 1 set output switch to **SE** to mute the 4.4mm output to avoid a pop sound during setup
- 2 connect 4.4mm balanced headphone jack
- 3 connect TUBE mini USB
- 4 connect your source smart phone tablet Windows / Mac
- 5 warm up for 30 seconds
- 6 set output switch to **BL** to unmute 4.4mm
- 7 lower volume level on your source before playing music. ENJOY 🎵🎵

**Connection for headphones with 3.5mm jack
[UNBALANCED]**

- 1 set output switch to **BL** to mute the 3.5mm output to avoid a pop sound during setup
- 2 connect 3.5mm unbalanced headphone jack
- 3 connect TUBE mini USB
- 4 connect your source smart phone tablet Windows / Mac
- 5 warm up for 30 seconds
- 6 set output switch to **SE** to unmute 3.5mm
- 7 lower volume level on your source before playing music. ENJOY 🎵🎵